



High lens, transparent T30HRT

Category: Series: Colour Accessory type: Positive opening: Accessories for pushbuttons and switches Accessories red lens no