



### Jumper, 2 poles VB2-2

Description: to connect adjacent terminals max. current load:  
The permissible total current running through the jumper must not exceed the rated current of the respective terminal blocks. 2 poles

Category: Accessories for terminal blocks  
Series: Accessories